System Operation



Initial Start-Up

From the moment your spa is plug in, it is automatically pre-set to operate until it reaches 100°F (38°C). This process could take up to 20 hours depending on the initial water temperature. The spa is also preset to filter the water for 1 hour per day (30) and the clock starts the second you plug it in. If after the first 7 minutes water is not flowing from the jets you may need to purge the pump. Please see page 16.

Temperature Adjustment 60°F-104°F (15°C-40°C)

When either of the Accu-temp pads are pressed once, the LCD will display the temperature which has been set. Each time either one of these pads are pressed again, the temperature will change by 1°. After 5 seconds, the LCD will automatically display the current spa temperature.

Jets. Press the pad to run the pump on and off. If left running, the pump will automatically turn off after 15 minutes.

Light Button

To turn the light on, press the button. Press again to turn it off, the light will automatically shut off after 4 hours.

Spa Water Maintenance. This function enables you to program the amount of water filtration time.

Press or and then to enter the programming mode. Once in the programming mode press or to select the filtration time.

00 In this mode there is no additional filtration.
30 In this mode the water will be filtered for 1 hour every day.
60 In this mode the water will be filtered for 2 hours every day.

To exit press

Standby Mode

This function allows you to disable the equipment when the filter needs to be serviced without disturbing the already programmed filtration time. Press or and then to enter the standby mode. All spa functions are disabled except for freeze control. To exit from standby press any button.

Error Messages :

OH "Overheat" (spa is deactivated)

DO NOT ENTER THE WATER. If the spa water has reached 108°F (44°C), remove the spa cover to cool the water. The spa will remain shut down until the water and the heater sensor cools to 104°F (40°C). At that point press any button to reset the spa. If the spa will not reset, shut off the power to the spa and call your dealer or service organi zation.

SN "Non Functional High Temp Sensor" (heater is deactivated)

Open sensor. Call your dealer or service center.